



- Ball may have deflated during shipping. See instructions for how to inflate.
- Le ballon peut s'être dégonfler pendant le transport. Voir instructions pour le regonfler.
- Es posible que la pelota se haya desinflado durante el transporte. Lea las instrucciones para inflarla.

**TOTSPORT™ EASYSORE™ BASKETBALL SET**

Ages: over 1 1/2 - 5 years  
 Please save sales receipt for proof of purchase.  
 Adult assembly required.

**⚠ WARNING:** Illus. 3 - 8: Follow net attachment illustrations 3 - 8 exactly! Always make sure net is attached completely. Make sure the label on the net is along the bottom edge (illus. 3).

**ASSEMBLY HINT:**  
 Illustration 10: if plug in base is tight, use pliers to remove or install. For added stability, fill base with up to 25 lbs. (11.3 Kg) of sand (not included).

- IF BALL NEEDS AIR:**
1. Use a standard athletic inflating needle available at most sporting goods stores.
  2. Moisten needle to insert into plug.
  3. A bicycle pump is recommended to pump air into ball.
  4. Inflate ball to approximately 5.125" (13 cm) diameter.

**CONSUMER SERVICES**  
[www.littletikes.com](http://www.littletikes.com)  
 TOLL-FREE NUMBER: United States: 1-800-321-0183  
 Little Tikes Consumer Services  
 2180 Barlow Rd.  
 Hudson, OH 44236